

Brick and Masonry Applications

Use a combination of masonry fasteners and PL Premium Adhesive to fasten Fypon products to brick or masonry structures. Counterdrill the fasteners and apply a non-shrinking filler in the interstices. Allow the wood filler to cure, then sand filled area flush. Touch up with paint.



Finishing Options

Moulded of high-density urethanes foam, Fypon moulded millwork products have an in-mold barrier coat, which becomes an integral part of the urethane foam as it cures.

After each piece is moulded and trimmed, we apply an exterior grade white primer paint with a built-in ultraviolet stabilizer.

Our products are impervious to moisture, so painted surfaces are not subject to the stages of chipping and peeling common with painted wood. Also, they are not subject to decay or insect damage.

PAINTING

Fypon products may be painted with any good quality latex or oil base paint. Usually one coat is all that is needed.

FAUX FINISHES

Our products are also suitable for many faux finishing techniques, including spraying, brushing, and antiquing using either oil base or latex paints.

WHITE COLOR MATCH - AVAILABLE AT SHERRIN-WILLIAMS[®]

To better service our customers nationwide, we have worked with Sherwin-Williams[®] to formulate a color and sheen match for our white paint that is applied at the factory. You can take this formulation to your local Sherwin-Williams dealer.

Formulation: Superior Exterior, Satin Lates

Paint Color Base: A98W51
LI - 1/84
W1 - 8 oz.
N1 - 1/128
Y5 - 1/128
R1 or R4 - 1/84

STAINING

Fypon products that are sold as Woodgrain/Grainite may be stained. Apply a good quality, non-oxidizing stain (ZAR,[®] Olympic Overcoat,[®] etc.) with a 2" natural bristle brush. Begin applying stain in a circular motion, then feather the stain in the direction of the grain. For a darker finish, apply a heavy coat of stain with light pressure. For a lighter finish, apply a thin coat of stain with more pressure.

USING CORROSION-RESISTANT FASTENERS AND PL PREMIUM ADHESIVE

Always use corrosion-resistant mechanical fasteners (nails or screws) and PL Premium Adhesive when installing Fypon products. This combination provides a secure, long lasting bond. Counterdrill all fasteners about 1/8 inch and fill with exterior grade white spackle. If desired, sand any minor imperfections and topcoat with a quality exterior latex or oil base paint. Fypon exterior millwork installations should be finished using a quality exterior grade silicone caulk to prevent water infiltration behind siding, windows and doors.

Some exterior millwork installations, in particular new construction (before siding is applied) may require a J-channel and/or flashing to prevent water infiltration. Installers must determine which installation technique is best for the specific situation.

DISCLAIMER

Please read these installation guidelines thoroughly before beginning installation. Please note that these guidelines are provided only to assist with the installation of mouldings and millwork products. Modified procedures may be required to cater to most specific situations, unique applications and local building codes. We encourage you to consult any circumstances around the installation of the products. Be sure to wear appropriate protective clothing, gloves and safety glasses when working with any tools. Installer should check for and release all electrical wiring within the proposed installation area, as required (be sure to disconnect all circuits prior to working with any electrical wiring and follow all applicable local electrical codes and safety procedures).